




- DE Montageanleitung
- FR Instructions de montage
- EN Assembly instructions
- IT Istruzioni per l'installazione
- ES Instrucciones de montaje
- NL Handleiding
- DK Monteringsvejledning
- PT Manual de instalação
- PL Instrukcja montażu
- CS Montážní návod
- SK Montážny návod
- ZH 组装说明
- RU Инструкция по монтажу
- HU Szerelési útmutató
- FI Asennusohje
- SV Monteringsanvisning
- LT Montavimo instrukcijos
- HR Uputstvo za instalaciju
- TR Montaj kılavuzu
- RO Instrucțiuni de montare
- EL Οδηγία συναρμολόγησης
- SL Navodila za montažo
- EI Paigaldusjuhend
- LV Montāžas instrukcija
- SR Uputstvo za montažu
- NO Montasjeveiledning
- BG Ръководство за монтаж
- SQ Udhëzime për të montimit
- AR





Cassetta 'C
28678000



Cassetta 'D Cassetta
28664000 U-88
28689000 28675000





hansgrohe

12/2006
9.06685.03

Hansgrohe · Austraße 5 · 9 · D-77761 Schiltach · Telefon +49 (0) 78 36/ 51-1282 · Telefax +49 (0) 7836/ 511440
EMail: info@hansgrohe.com · Internet: www.hansgrohe.com